

# TAKING DOWN your INSTANT BACKSTOP®



1. Remove all **Suction Cups** and **Tethers**. If outdoors, remove **Threaded T-Handle Pegs**.



2. Release both **Slipcover** straps from metal buckles attached to the grommets.



3. Remove **Crutch Tips** from both ends of **Support Pole**, then remove ends of **Support Pole** from both grommets.




4. Release both **Slipcover** and **Support Pole** from **INSTANT BACKSTOP®** frame by unfastening **Velcro® Straps**. Place both **Slipcover** and **Support Pole** aside.



5. Put one side of **INSTANT BACKSTOP®** frame on top of the other. This will form a 9-foot circle.



6. Stand the **INSTANT BACKSTOP®** up on its side.



7. Stand at the opposite end of the **JUGS** logo. Walk in front of the screen towards the logo. Put downward pressure on the middle of the screen. The **INSTANT BACKSTOP®** will form a figure eight.



8. Grab the half of the figure eight without the logo and fold it on top of the half with the logo. You should now have a 52-inch circle.



9. Keeping control of the circle (if you release too early the **INSTANT BACKSTOP®** can pop open), **put on the retention strap**.



10. Take folding **Support Pole** out of the **Slipcover**. Fold the **Support Pole**. Place your folded and strapped **INSTANT BACKSTOP®** into the **Carrying Bag** along with the **Support Pole** and **Slipcover**.

If you need more information about this product or any other **JUGS** product or service, please contact the manufacturer:



In the USA and Canada, call toll-free: 1-800-547-6843.

For International Orders, call collect: 0-503-692-1635.

Our fax number is 1-503-691-1100.

Visit our website at [www.jugssports.com](http://www.jugssports.com).

Se habla español.

© 2006 JUGS Sports  
IBS1-0808

## INSTRUCTIONS



### INSTANT BACKSTOP®



#### ⚠ WARNING READ THIS NOW

When this **INSTANT BACKSTOP®** is being handled it can suddenly and unexpectedly open to full size. **BEFORE REMOVING INSTANT BACKSTOP® FROM CARRYING BAG, BE SURE TO READ AND UNDERSTAND THESE INSTRUCTIONS FOR SETTING UP AND TAKING DOWN THE INSTANT BACKSTOP®** You must be at least **EIGHTEEN YEARS OF AGE** and in good health to set up and take down this screen. Before removing the **INSTANT BACKSTOP®** from the carrying bag or retention strap, be sure you have an area of at least 20 feet clear all around you. Do not attempt to unfold or set up on sloping ground. Failure to heed this warning could result in **SERIOUS INJURY**.

For further information, contact manufacturer: USA & Canada, call toll-free: 1-800-547-6843 International, call collect: 0-503-692-1635

#### SAVE THESE INSTRUCTIONS

⚠ **WARNING** Always remember to place the **ELASTIC RETENTION STRAP** onto the folded **INSTANT BACKSTOP®**. Always transport the screen folded and **STRAPPED** in its **CARRYING BAG**.

# SETTING UP your INSTANT BACKSTOP®



1. Grasping the edge of the net frame, remove screen from carrying bag and remove the elastic retention strap.




2. Holding the net frame together, toss away from your body onto a clear, level area.



3. The INSTANT BACKSTOP® should now be lying flat on the ground in a 9-foot circle.




4. Put folding **Support Pole** together at its maximum length of 25 feet. Slide blue **Slipcover** over assembled folding **Support Pole**.




5. Put one end of the folding **Support Pole** into one of the two grommets at the bottom of the **INSTANT BACKSTOP®**. Place the strap from the **Slipcover** into the metal buckle attached to the grommet. For indoor use only, please attach **Crutch Tip** to bottom of **Support Pole** once the **Support Pole** is through the grommet.



8. With two people, one on each side, raise the **INSTANT BACKSTOP®** to an upright position. **NOTE:** The bottom of the **INSTANT BACKSTOP®** must be spread to its maximum width to stand properly.



9. The **Support Pole** with **Slipcover** must be on the inside of the **INSTANT BACKSTOP®** frame at all points.



6. Attach the **Support Pole** with **Slipcover** to the sides and top of the **INSTANT BACKSTOP®** with the 15 **Velcro® Straps**.



7. Place the other end of the **Support Pole** into the other grommet. Place the strap from the **Slipcover** into the metal buckle attached to the grommet. For indoor use only, please attach **Crutch Tip** to bottom of **Support Pole** once the **Support Pole** is through the grommet.



10. With two people, one on each side, pull the **Red Straps** at the front of the **INSTANT BACKSTOP®** to a 45° angle to the ground. When both **Red Straps** are tight and the **INSTANT BACKSTOP®** is upright, attach the end of the **Red Straps** to the floor with **Suction Cups** and **Tethers**. If outdoors, use **Threaded T-Handle Pegs** to secure **Red Straps** to ground.



11. Secure the **D-Rings** on both sides of **INSTANT BACKSTOP®** using **Suction Cups** and **Tethers**. If outdoors, use **Threaded T-Handle Pegs** to secure **D-Rings** to ground. Your **INSTANT BACKSTOP®** is now ready for use.