

If you need more information about this product or any other JUGS product or service, please contact the manufacturer:



In the USA and Canada, call toll-free: 1-800-547-6843.

For International Orders, call collect: 0-503-692-1635.

Our fax number is 1-503-691-1100.

Visit our website at [www.jugssports.com](http://www.jugssports.com).

Se habla español.

© 2008 JUGS Sports  
SmBIPSI-0808

# INSTRUCTIONS



## JUGS **SMALL-BALL**® Instant Protective Screen



### **⚠ WARNING READ THIS NOW**

When this screen is being handled, it can suddenly and unexpectedly open to full size. **BEFORE REMOVING SCREEN FROM CARRYING BAG, BE SURE TO READ AND UNDERSTAND THESE INSTRUCTIONS FOR UNFOLDING AND FOLDING THE SCREEN.** You must be at least **EIGHTEEN YEARS OF AGE** and in good health to unfold and fold this screen. Before removing the screen from the carrying bag or retention strap, be sure you have an area of at least 20 feet clear all around you. Do not attempt to unfold or set up on sloping ground. Failure to heed this warning could result in **SERIOUS INJURY**.

Questions: Call JUGS Toll Free: 1-800-547-6843.  
Outside the USA & Canada: 0-503-692-1635.

**SAVE THESE INSTRUCTIONS**

# TERMINOLOGY




Carrying Bag



Retention Strap




Pegs



Screen


## UNFOLDING the JUGS **SMALL-BALL**® Instant Protective Screen

1



1. Hold onto the edge of the frame, pull the screen out of the carrying bag and remove the elastic retention strap.

2



2. Hold the net frame together and toss it away from your body onto clear, level ground.

3



3. Tilt the screen upright, adjust the straps and push the pegs through the peg loops and into the ground.

### **⚠ WARNING**

Inspect your JUGS **SMALL-BALL**® Instant Protective Screen before each practice. Do not use if you see excessive wear or damaged parts.

**FOLDING  
the JUGS  
SMALL-BALL®  
Instant  
Protective  
Screen**



1. Loosen the straps and remove all pegs.



2. Tip your JUGS **SMALL-BALL®** Instant Protective Screen over, backwards, and onto the ground.



3. Put the back base frame and the front base frame together—with the JUGS logo on top.




4. Hold onto the middle of the top of the net frame, and stand in front of the JUGS logo on the front (vinyl) base.



5. With both hands, pull the top of the net frame toward the top of the vinyl base **on the JUGS logo.**




6. With your left foot, press down and hold the top edge of the net frame above the JUGS logo.



7. Keep your left foot on top of the net frame, and grasp both the left and right semicircles.



8. With your left hand, push the left side down towards the JUGS logo, forming a 27"-diameter circle. Do the same with the right side.



9. Hold the two circles together securely—if you release too early, the screen can pop open. Wrap the retention strap around them.



10. Put your folded and strapped screen into the carrying bag.



**The JUGS **SMALL-BALL®** Instant Protective Screen CANNOT BE USED WITH official-weight baseballs or softballs.**



**Always remember to wrap the ELASTIC RETENTION STRAP around the folded screen. Always transport the screen folded and STRAPPED in its CARRYING BAG.**