

JUGS TOSS™ Machine

Introduction

This manual contains important information concerning the proper use and care of your JUGS TOSS Machine.

PLEASE READ THIS MANUAL **COMPLETELY BEFORE OPERATING** YOUR JUGS TOSS MACHINE.

Check for shipping damage

Even though your JUGS TOSS Machine may appear undamaged. it is possible for internal part to be damaged even if the external case is undamaged. If your machine is damaged, please contact us at the following number: I-800-547-6843: or, if you are outside the USA or Canada, please call, collect, 503-692-1635.

Save the original shipping carton

The original carton should be used in case ever becomes necessary to ship your JUGS Toss Machine for service under warranty.

Positioning your JUGS TOSS Machine


Position your JUGS TOSS Machine as shown in the diagram below. Move your JUGS TOSS Machine farther away or closer to the batter, to set the desired height. NEVER HIT BALLS DIRECTLY TOWARDS YOUR JUGS TOSS MACHINE.

!! IMPORTANT WARNINGS !!

DO NOT STAND DIRECTLY IN FRONT OF THE TOSS MACHINE. DO NOT INSERT HANDS OR FOREIGN OBJECTS INTO THE MACHINE.

JUGS TOSS Tips

Position your JUGS TOSS so that it tosses the ball over the front edge of the plate. This teaches the hitter to aggressively go after the ball and make contact out in front of the plate in the "power zone."



Hit in the direction of the arrow.



Operating Your JUGS TOSS Machine

Load balls, starting from the bottom (Ejection Point) of the ramp. Do not load balls by letting them roll down the ramp, as this may cause the first few balls to be positioned incorrectly and not toss properly.

JUGS TOSS is designed to work with standard-size baseballs, softballs up to 12 inches in diameter, JUGS Sting-Free® balls and Reduced Injury Factor (RIF) baseballs. The toss height will be high with lighter balls. It is normal for the toss height to vary somewhat, even with baseballs, due to the effect of the seams.

Push the Power Switch to the "ON" position. JUGS TOSS will toss a ball approximately every five seconds. The JUGS TOSS Machine should be turned OFF when there are no more balls to be thrown. For the longest spring life, it is best to turn off the JUGS TOSS Machine when the "flipper" has just completed its throwing motion and before the spring begins to stretch again.

Battery Charging

To charge the internal battery, plug the battery charger into the jack on top of your JUGS TOSS Machine and then into a live AC outlet. The most common cause of a battery not charging is a dead AC outlet.

CHARGE BATTERY IMMEDIATELY AFTER EACH USE.

Battery Life

A fully charged battery will normally provide over six hours of practice time. It requires approximately 12 hours to fully recharge the battery. Undercharging the battery will result in shortened playing time and may decrease the life of the battery. To extend the life of the battery, charge it for 24 continuous hours once each month. If the battery is not holding a full charge, or has been discharged for some time, charge it for five straight days. However, never charge the battery for more than five straight days.

Fuse

The JUGS TOSS Machine is protected by an internal 3-amp slo-blow fuse. Call us if you suspect the fuse has blown.

Maintenance and Cleaning

JUGS TOSS requires no regular maintenance other than routine cleaning. To clean the JUGS TOSS Machine case, use a slightly damp cloth. Do not use chemicals or abrasive cleaners.

Storage

Store JUGS TOSS in a clean dry place. Do not store the JUGS TOSS Machine in the trunk of a car. Heat build-up inside a car trunk can reach 180 degrees, which may damage your JUGS TOSS Machine.

Charge the battery before storing. Charge the battery for at least one day every three months while in storage. Do not store your JUGS TOSS Machine with the battery charger plugged in.

Service or Questions

If your JUGS TOSS Machine should ever need service, or if you have any questions regarding your JUGS TOSS Machine, please call our Service Department, toll free, at 1-800-547-6843.

Outside the USA and Canada, call collect at 503-692-1635. You may fax your questions to 503-691-1100.

JUGS TOSS MACHINE LIMITED WARRANTY

Warranty Period

JUGS Sports warrants JUGS TOSS for a period of two years from the date of original purchase. The battery is warranted for a period of six months.

Scope of Warranty

This warranty covers all defects in material and workmanship. The following are not covered by the warranty:

- Units on which the serial number has been deleted, modified or removed.
- Units damaged by accident, misuse, abuse, neglect, unauthorized product modification, or failure to follow instructions contained in the owner's manual.
- Units damaged by repair by anyone not authorized by JUGS Sports.
- Units damaged during shipment (claims must be presented to the shipper).

Who is protected

This warranty protects the original purchaser and any subsequent owner(s) during the warranty period, so long as the JUGS TOSS Machine was purchased in the United States and a copy of the original bill of sale is submitted whenever warranty service is required.

What JUGS Sports will pay for

We will pay for all labor and materials to repair a warrantable defect. We will also pay shipping charges to return the JUGS TOSS Machine to you.

How to obtain warranty service.

Before the JUGS TOSS Machine is returned for repair, an RMA number must be issued. Call or write JUGS Sports for this information. Include this number on the package and deliver the unit, Postage and Shipping prepaid, to JUGS Sports / 11885 S.W. Herman Rd / Tualatin, Oregon 97062. Include your name, address, daytime telephone number, copy of original bill of sale, and a brief description of the problem.

Limitation of implied warranties

All implied warranties, including fitness for a particular purpose and merchantability are limited in duration to the length of this warranty. We neither assume nor authorize any representative or other person to assume for us any other liability in connection with the sale or shipment of our products.

Limitations of incidental or consequential damages

JUGS Sports is not responsible for any incidental or consequential damages of any kind. Our liability is limited to the repair or replacement, at our option, of a defective product. Some states do not allow limitations on how long an implied warranty lasts and/or do not allow the exclusion of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.



In the USA and Canada, call toll free:
1-800-547-6843.
Internationally, call collect: 0-503-692-1635.
Our fax number is 503-691-1100.
Visit our web site at www.jugssports.com.

Se habla español.

© 2008 JUGS Sports TMI-0808