

INDOOR ANCHORING PACKAGE

Use your **MINI INSTANT GOOOOAL!**® indoors with the optional indoor anchoring package. (Package includes 3 Suction Cups with Tethers.)



If you need more information about this product or any other JUGS product or service, please contact the manufacturer:



In the USA and Canada, call toll-free: 1-800-547-6843.

For International Orders, call collect: 0-503-692-1635.

Our fax number is 1-503-691-1100. Visit our website at www.jugssports.com.

Se habla español.

© 2008 JUGS Sports
MIGSNI-1008

INSTRUCTIONS



SOCCER NET




⚠ WARNING READ THIS NOW.

When this **MINI INSTANT GOOOOAL!**™ is being handled, it can suddenly and unexpectedly open to full size. **BEFORE REMOVING THE MINI INSTANT GOOOOAL FROM THE CARRYING BAG, BE SURE TO READ AND UNDERSTAND THESE INSTRUCTIONS FOR UNFOLDING AND FOLDING THE MINI INSTANT GOOOOAL!**™ You must be at least **EIGHTEEN YEARS OF AGE** and in good health to unfold and fold this screen. Before removing the **MINI INSTANT GOOOOAL!** from the carrying bag or retention strap, be sure you have an area of at least 20 feet clear all around you. Do not attempt to unfold or set up on sloping ground. Failure to heed this warning could result in **SERIOUS INJURY**.

Call JUGS SPORTS
Toll Free: 1-800-547-6843.
Outside the USA, Collect: 503-692-1635.

SAVE THESE INSTRUCTIONS

MINI INSTANT GOOOOAL!®



TERMINOLOGY



THREADED T-HANDLE PEG



CARRYING BAG



ELASTIC RETENSION STRAP


UNFOLDING the JUGS Mini Instant GOOOOAL™



1. Grasping the edge of the **MINI INSTANT GOOOOAL!**® frame, remove **MINI INSTANT GOOOOAL!**® from **carrying bag** and remove **elastic retention strap**.



2. Holding the **MINI INSTANT GOOOOAL!**® frame together, toss it away from your body onto a clear, level area.



3. Tilt the **MINI INSTANT GOOOOAL!**® upright. Insert **T-Handle Pegs** into the three **peg loops** (on the two side flaps and middle loop on back of the **MINI INSTANT GOOOOAL!**®).

⚠ WARNING Always inspect your JUGS **MINI INSTANT GOOOOAL!**™ before each use. Do not use the **JUGS MINI INSTANT GOOOOAL!**™ if it shows signs of excessive wear or damaged components.



FOLDING the JUGS Mini Instant GOOOOAL™



1. Remove the **Threaded T-Handle Pegs** and stand directly in front of your **MINI INSTANT GOOOOAL!**®. With both hands, grab the **MINI INSTANT GOOOOAL!**® at the **Red Side Tabs** on each side of frame.



2. Bring your hands together in front of you.



3. Rotate and cross hands and allow the **MINI INSTANT GOOOOAL!**® to close. When closed properly, the **MINI INSTANT GOOOOAL!**® should fold into a 30"-diameter circle.



4. Keep the **MINI INSTANT GOOOOAL!**® tightly folded (if you release too early, it can pop open), **fasten it together with the retention strap** and place the **MINI INSTANT GOOOOAL!**® in its carrying bag.

⚠ WARNING Always remember to place the ELASTIC RETENTION STRAP around the folded JUGS **MINI INSTANT GOOOOAL!**®. Always transport the screen folded and STRAPPED in its CARRYING BAG.